


Programming the FPGA Configuration Flash

Setting Quartus to generate *.pof




Quartus must be configured to generate a Programmers Object File (pof) Which is suited to be programmed into the External Flash (Configuration Device)



Setting Device Options






After saving the menues, recompile the device and check whether the *.pof file is generated lokated in the *synthesis* or *output* directory

Programming



- Set the RUN-PRG Switch on the DE115 board to PRG
- 2. Open the Programmer and set it to Active Serial Programming
- 3. Remove the .sof and add the .pof file



- 4. Programm and Verify the device
- 5. Set the Switch back to RUN.
- 6. Turn on and off the power of the board to load the configuration